



4" and 6" Lift Systems for 2008 4WD Ford Super Duty

Both lifts feature either gas or diesel specific replacement coil springs. Radius arm lowering brackets, track bar relocation bracket, proper compression travel control, sway bar links, you name it... if it's needed, it's included. Three different performance shocks are offered, plus tons of optional accessories including our front 4-link conversion.



Dual steering stabilizer kit with SS series silver Zinc plated cylinders now available for all lifted Super Dutys... part #92730!

New Superlift pitman arm design translates into less effort required at the steering wheel and easier turning! Pitman arm used with 6" lift only.



2008 Ford Super Duty equipped with Superlift 6" Suspension

Are these products in the current Superlift catalog #115?

Not all; see below.

Make these catalog additions / revisions, or print-out the new chart attachment then insert into the catalog:

Page 181 - In LIFT HEIGHT & METHOD chart boxes for 6" lifts, replace REAR 5" BLOCK KIT with REAR 2.5" BLOCK KIT & ADD-A-LEAFS.

Page 180 and 181 - In STEERING STABILIZERS chart box, add #92730, dual steering stabilizer kit with SS series silver Zinc plated cylinders.

Installation Notes:

- **Page 180 and 181** - On both 4" and 6" lifts, add new note #155: Most Super Duty vehicles have a 1.91" tall factory block (measured at block's rear facing end) and do NOT have top-mounted overload springs; this is Superlift's standard configuration and is included in the Master Pack. If equipped with 1.91" factory block AND top-mount overloads OR 3.71" factory block WITHOUT top-mount overloads: order either block kit # 9197, or set of longer U-bolts (qty. one # 11664). If equipped with 3.71" factory block AND top-mount overloads: order either block kit # 9198, or set of longer U-bolts (qty. one # 11674).

- **Page 180 and 181** - Omit note #125.

- **Page 181** - Add new note #157: Front Bulletproof brake hoses included in 6" lift.

SUSPENSION SYSTEMS - FORD

F-250 / 350 SUPER DUTY 4WD 2008

4" FRONT / 2½" REAR

LIFT HEIGHT & METHOD	MASTER PACK	(QTY) & PART NUMBER - BASE KIT COMPONENTS		
V-8 GAS ENGINE				
FRONT COMPLETE SYSTEM INCLUDES: COIL SPRINGS RADIUS ARM BRACKETS TRACK BAR BRACKET REAR 2½" BLOCK KIT SEE OPTIONS BELOW	K853 SUPERIDE OR K853B SS - BILSTEIN OR K853R SSR - REMOTE	(1) 9064 FRT. KIT BOX W/ SUPERIDE SHOCKS	NOTES: 119 155	
		OR (1) 9064B FRT. KIT BOX W/ SS-BILSTEIN SHKS		
OR (1) 9064R FRT. KIT BOX W/ SSR-REMOTE SHKS				
PLUS (1) 295 FRONT COIL SPRINGS				
(1) 9097 REAR BLOCK KIT				
V-10 / DIESEL ENGINE				
FRONT COMPLETE SYSTEM INCLUDES: COIL SPRINGS RADIUS ARM BRACKETS TRACK BAR BRACKET REAR 2½" BLOCK KIT SEE OPTIONS BELOW	K854 SUPERIDE OR K854B SS - BILSTEIN OR K854R SSR - REMOTE	(1) 9064 FRT. KIT BOX W/ SUPERIDE SHOCKS		
		OR (1) 9064B FRT. KIT BOX W/ SS-BILSTEIN SHKS		
OR (1) 9064R FRT. KIT BOX W/ SSR-REMOTE SHKS				
PLUS (1) 294 FRONT COIL SPRINGS				
(1) 9097 REAR BLOCK KIT				
OPTIONS				
STEERING STABILIZERS	4-LINK CONVERSION KITS		BULLETPROOF BRAKE HOSES	
92694 DUAL STEERING STAB. KIT - STANDARD	9033 4-LINK KIT WITH SUPERLIFT SYSTEM	91540 FRONT BULLETPROOF BRAKE HOSES		
92730 DUAL STEERING STAB. - SS (STAINLESS)	9044 4-LINK UNIVERSAL KIT - ALL BRANDS	91515 REAR BULLETPROOF BRAKE HOSE		
eXTREME RING	CARRIER BEARING RELOCATOR		MULTI-SHOCKS - FRONT	
50115 DIFF. PROTECTOR - DANA 50/60 FRONT	9649 CARRIER BEARING DROP KIT	60132 FRONT DUAL SHOCK KIT BRACKETS		
STAINLESS STEEL ACCESSORIES	(FOR VEHICLES WITH 2-PIECE REAR DRIVE SHAFT)	(QTY) & SHOCK REQUIRED FOR MULTI-SHOCK		
30605 RADIUS ARMOR, RADIUS ARM COVERS		(2) 88510 SUPERIDE SHOCKS		
9658 FRONT SKID PLATE W/LOGO		(2) BE5-6681-H5 SELECT SERIES by BILSTEIN (SS)		
TORQUE MAX STANDARD SERIES	TORQUE MAX SELECT SERIES	(2) 95021 SELECT SERIES REMOTE RES. (SSR)		
TRACTION DEVICE	TRACTION DEVICE	(NOTE: THE STOCK LOCATION SHOCK IS REUSED, ORDER (4) SHOCKS IF CONVERTING TO NEW SHOCK SERIES.)		
20500 EXTENDED CAB - SHORT BED	20505 EXTENDED CAB - SHORT BED			
20510 CREW CAB - SHORT BED	20515 CREW CAB - SHORT BED			
20520 REG., EXT., & CREW CABS - LONG BED	20525 REG., EXT., & CREW CABS - LONG BED			

NOTES:

119.Dually applications require different U-bolts. Measure stock U-bolts and refer to U-bolt specification chart to order correct u-bolts.

155.Most Super Duty vehicles have a 1.91" tall factory block (measured at block's rear facing end) and do NOT have top-mounted overload springs; this is Superlift's standard configuration and is included in the Master Pack. If equipped with 1.91" factory block AND top-mount overloads OR 3.71" factory block WITHOUT top-mount overloads: order either block kit #9197, or set of longer U-bolts (qty. one #11664). If equipped with 3.71" factory block AND top-mount overloads: order either block kit #9198, or set of longer U-bolts (qty. one #11674).

**Revised Page 180
Superlift Catalog #115**

SUSPENSION SYSTEMS - FORD

F-250 / 350 SUPER DUTY 4WD 2008

6" FRONT / 5" REAR

LIFT HEIGHT & METHOD	MASTER PACK	(QTY) & PART NUMBER - BASE KIT COMPONENTS	FOR REAR SPRING APPLICATION ADD: (QTY) & PART NUMBER	
V-8 GAS ENGINE				
FRONT COMPLETE SYSTEM INCLUDES: COIL SPRINGS RADIUS ARM BRACKETS TRACK BAR BRACKET REAR 2½" BLOCK KIT & ADD-A-LEAFS SEE OPTIONS BELOW	K855 SUPERIDE OR K855B SS - BILSTEIN OR K855R SSR - REMOTE	(1) 9066 FRT. KIT BOX W/ SUPERIDE SHOCKS	(2) 01-186 REAR LEAF SPRINGS	117
		OR		119
		(1) 9066B FRT. KIT BOX W/ SS-BILSTEIN SHKS		155
		OR		157
		(1) 9066R FRT. KIT BOX W/ SSR-REMOTE SHKS		
		PLUS		
(1) 297 FRONT COIL SPRINGS				
(1) 9097 REAR BLOCK KIT				
(1) 2570 ADD-A-LEAF KIT				
V-10 / DIESEL ENGINE				
FRONT COMPLETE SYSTEM INCLUDES: COIL SPRINGS RADIUS ARM BRACKETS TRACK BAR BRACKET REAR 2½" BLOCK KIT & ADD-A-LEAFS SEE OPTIONS BELOW	K856 SUPERIDE OR K856B SS - BILSTEIN OR K856R SSR - REMOTE	(1) 9066 FRT. KIT BOX W/ SUPERIDE SHOCKS		
		OR		
		(1) 9066B FRT. KIT BOX W/ SS-BILSTEIN SHKS		
		OR		
		(1) 9066R FRT. KIT BOX W/ SSR-REMOTE SHKS		
		PLUS		
(1) 296 FRONT COIL SPRINGS				
(1) 9097 REAR BLOCK KIT				
(1) 2570 ADD-A-LEAF KIT				
OPTIONS				
STEERING STABILIZERS		4-LINK CONVERSION KITS		BULLETPROOF BRAKE HOSES
92694 DUAL STEERING STAB. KIT - STANDARD		9036 4-LINK UNIVERSAL KIT - ALL BRANDS		91515 REAR BULLETPROOF BRAKE HOSE
92730 DUAL STEERING STAB. - SS (STAINLESS)				
eXTREME RING		CARRIER BEARING RELOCATOR		MULTI-SHOCKS - FRONT
50115 DIFF. PROTECTOR - DANA 50/60 FRONT		9669 CARRIER BEARING DROP KIT (FOR VEHICLES WITH 2-PIECE REAR DRIVE SHAFT)		60132 FRONT DUAL SHOCK KIT BRACKETS (QTY) & SHOCK REQUIRED FOR MULTI-SHOCK
STAINLESS STEEL ACCESSORIES				(2) 88520 SUPERIDE SHOCKS
30605 RADIUS ARMOR, RADIUS ARM COVERS				(2) BE5-6646-H5 SELECT SERIES by BILSTEIN (SS)
9658 FRONT SKID PLATE W/LOGO				(2) 95022 SELECT SERIES REMOTE RES. (SSR)
TORQUE MAX STANDARD SERIES		TORQUE MAX SELECT SERIES		(NOTE: THE STOCK LOCATION SHOCK IS REUSED, ORDER (4) SHOCKS IF CONVERTING TO NEW SHOCK SERIES.)
TRACTION DEVICE		TRACTION DEVICE		
20500 EXTENDED CAB - SHORT BED		20505 EXTENDED CAB - SHORT BED		
20510 CREW CAB - SHORT BED		20515 CREW CAB - SHORT BED		
20520 REG., EXT., & CREW CABS - LONG BED		20525 REG., EXT., & CREW CABS - LONG BED		

NOTES:
117
119
155
157

NOTES:

117..Factory rear overload springs cannot be retained if replacement rear springs are used.

119..Dually applications require different U-bolts. Measure stock U-bolts and refer to U-bolt specification chart to order correct U-bolts.

155..Most Super Duty vehicles have a 1.91" tall factory block (measured at block's rear facing end) and do NOT have top-mounted overload springs; this is Superlift's standard configuration and is included in the Master Pack. If equipped with 1.91" factory block AND top-mount overloads OR 3.71" factory block WITHOUT top-mount overloads: order either block kit #9197, or set of longer U-bolts (qty. one #11664). If equipped with 3.71" factory block AND top-mount overloads: order either block kit #9198, or set of longer U-bolts (qty. one #11674).

157..Front Bulletproof brake hoses included in kit box.

Revised Page 181
Superlift Catalog #115

2008 Ford Superduty 4" and 6" Suspensions								
Part #	Jobber	UPC	Box Deminions	Part #	Jobber	UPC	Box D	
01-186	379.95	804260069810	No Box	9066R	1,539.99	804260069711	33x	
11664	69.88	804260005504	19x2.75x5.375	9097	91.00	804260015152	22.5	
11674	69.88	804260005535	19x2.75x5.375	9197	91.00	804260015268	22.5	
20500	590.90	804260068998	73x14x9.375	9198	91.00	804260070397	22.5	
20505	862.99	804260069001	73x14x9.375	91515	94.62	804260037390	Pt	
20510	590.90	804260069018	73x14x9.375	91540	216.36	804260068950	Pt	
20515	761.62	804260069025	73x14x9.375	92694	215.99	804260068967	22.5x1	
20520	617.16	804260069032	73x14x9.375	92730	446.36	804260035891	22.5x1	
20525	774.75	804260069049	73x14x9.375	95021	216.41	804260035907	3	
2570	91.33	804260007645	51x4.5x3.25	95022	216.41	804260035914	3	
294	321.77	804260007263	25.625x16.5x7.875	9649	30.07	804260022044	11x2	
295	320.37	804260007270	25.625x16.5x7.875	9658	251.00	804260006112	24.75x3	
296	323.28	804260024420	25.625x16.5x7.875	9669	45.74	804260022037	11x2	
297	322.20	804260024437	25.625x16.5x7.875	BE5-6646-H5	111.83	804260023485	3	
30605	224.47	804260035426	22.5x7x5.375	BE5-6681-H5	111.83	804260023492	3	
50115	160.20	804260009113	13.125x13.125x3.5	K853	998.29	804260069124	44x	
60132	383.46	804260069056	22.5x11.25x5.375	K853B	1,212.49	804260069131	44x	
88510	51.66	804260026936	3x3x24	K853R	1,430.77	804260069148	44x	
88520	51.66	804260068233	3x3x24	K854	999.69	804260069155	44x	
9033	768.66	804260068929	34x16.5x7.5	K854B	1,213.89	804260069162	44x	
9036	896.25	804260048884	33x13x7.5	K854R	1,432.17	804260069179	44x	
9044	896.25	804260068936	34x16.5x7.5	K855	1,374.34	804260069834	44x	
9064	586.92	804260068202	25.625x16.5x7.875	K855B	1,623.22	804260069841	44x	
9064B	801.12	804260068974	25.625x16.5x7.875	K855R	2,041.52	804260069858	44x	
9064R	1,019.40	804260068981	25.625x16.5x7.875	K856	1,375.42	804260069865	44x	
9066	869.81	804260069582	33x16.5x10.5	K856B	1,624.30	804260069612	44x	
9066B	1,118.69	804260069599	33x16.5x10.5	K856R	2,042.60	804260069872	44x	