

Superlift 4" Lift System for Ford Ranger 4WD

**Now Fits Up To
2009 Models**



Superlift #K358 (consists of #9637, #9631, #2338) currently in the field fits 2000-2005 Rangers. Lift systems shipped by Superlift as of today (12-15-08) will also fit up to 2009 models. This is running change; neither the K-number nor Kit Box part numbers have changed. For a period of time, Ranger systems will state "Fits up to 2009 Model" on the part number label, just above the Control Number.

If you have #K358, #9637, #9631 and #2338 in stock, order free Hardware / Instruction Bag #77-9910 (one per lift system) to update the lift system to also fit 2006-2009 Rangers. Simply insert #77-9910 into the #9631 Kit Box, and apply the supplied "Fits up to 2009 Model" decal to the appropriate boxes.

We also now offer New #10914, which is the U-bolt kit required when installing the Superlift Ranger lift on any FX4 model Ranger.

1998-2009 Ford Ranger 4WD				
Part #	Description	Jobber	UPC	Box Deminsions
10914	FX4 rear ubolt kit	49.54	804260028299	19 x 2-3/4 x 5-3/8
77-9910	Update kit for existing 9631 stock	FREE	804260090296	Poly Bag

- Make the following edits in Superlift Catalog #115**
- Page 43 - Update page header from 1996-2005 to 1996-2009
 - Page 43 - In Available Lifts box, update last Ranger listing to 1998-09
 - Page 189 - Update chart header from 1998-05 to 1998-09
 - Page 189 - In chart, update K358 to fit 2000-09.
 - Page 189 - Below chart, add FX4 U-bolt kit data and Jobber price.

