



2.5", 4" and 6" Lifts for 2006-2008 4WD Dodge 1500



2.5" Level-It Kit

2.5" Level-It kit allows the use of both 17" and 20" factory wheels and makes room for up to 35" tall tires. Must not use with TRX model.

4" Lift

4" Lift clears up to 35 x 12.50 tires on 18" wheels with a maximum backspacing of 5", or 35 x 12.50 tires on 20" wheels with a maximum backspacing of 5.5".

6" Lift

6" Lift clears up to 37 x 12.50 tires on 18" wheels with a maximum backspacing of 5", or 37 x 12.50 tires on 20" wheels with a maximum backspacing of 5.5".

4" and 6" Lift Systems' Features:

- Front lift choice of new strut towers (no strut disassembly required), or replacement Superide Select SS series gas monotube strut bodies by Bilstein.
- Replacement knuckles yield best possible alignment specs. Front track width is not increased and factory turning radius is retained.
- Front lower control arm crossmembers laser cut from 3/16" material.
- Belly pan, constructed of 1/4" material, connects crossmembers and protects differential.
- Retains front anti-sway bar link extensions factory "service for life" links.

TRX Model - Both Superlift's 4" and 6" systems will fit Dodge's TRX. Some additional Superlift components are needed if using the strut spacer lift version (see Application Chart for details). Note that the TRX factory ride height is approximately 1" taller than the standard 1500, so you will gain 1" less lift than stated.

Our 2.5" Level-It front lift system must not be installed on TRX models.



#K118
6" Dodge Lift



**PICKUP - RAM 1500 (1/2 TON) 4WD
2006-08**

LEVEL-IT SYSTEM: 2 1/2" FRONT / 0" REAR

LIFT HEIGHT & METHOD	MASTER PACK	(QTY) & PART NUMBER - BASE KIT COMPONENTS	NOTE
STRUT EXTENSION		(1) 40002 LEVEL-IT KIT BOX	166

4" FRONT / 2 1/2" REAR

LIFT HEIGHT & METHOD	MASTER PACK	(QTY) & PART NUMBER - BASE KIT COMPONENTS	NOTE
4WD STRUT SPACER STANDARD SYSTEM			
FRONT KIT WITH STRUT SPACERS AND KNUCKLES	K117 SUPERIDE	(1) 4590 FRONT KIT WITH KNUCKLES	
REAR ADD-A-LEAFS		(1) 4591 FRONT KIT BOX	
		(1) 4592 BELLY PAN	
		(1) 4597 KIT BOX W/ SUPERIDE SHOCKS	
4WD REPLACEMENT STRUT BILSTEIN SYSTEM			
FRONT KIT WITH REPLACEMENT STRUTS AND KNUCKLES	K117B BILSTEIN	(1) 4590 FRONT KIT WITH KNUCKLES	
REAR ADD-A-LEAFS		(1) 4591 FRONT KIT BOX	
		(1) 4592 BELLY PAN	
		(1) 4597B KIT BOX W/ BILSTEIN SHOCKS	

6" FRONT / 4 1/2" REAR

LIFT HEIGHT & METHOD	MASTER PACK	(QTY) & PART NUMBER - BASE KIT COMPONENTS	NOTE
4WD STRUT SPACER STANDARD SYSTEM			
FRONT KIT WITH STRUT SPACERS AND KNUCKLES	K118 SUPERIDE	(1) 4590 FRONT KIT WITH KNUCKLES	
REAR BLOCKS & ADD-A-LEAFS		(1) 4591 FRONT KIT BOX	
		(1) 4592 BELLY PAN	
		(1) 4598 KIT BOX W/ SUPERIDE SHOCKS	
4WD REPLACEMENT STRUT BILSTEIN SYSTEM			
FRONT KIT WITH REPLACEMENT STRUTS AND KNUCKLES	K118B BILSTEIN	(1) 4590 FRONT KIT WITH KNUCKLES	
REAR BLOCKS & ADD-A-LEAFS		(1) 4591 FRONT KIT BOX	
		(1) 4592 BELLY PAN	
		(1) 4598B KIT BOX W/ BILSTEIN SHOCKS	

NOTES:

- 165...When using 4" strut spacer system on TRX4 model, MUST also order #4595. Not required on Bilstein system.
- 166...2.5" Level-It system MUST NOT be installed on TRX4 models.
- 167...When using 6" strut spacer system on TRX4 model, MUST also order #4580. Not required with Bilstein system

2006-2008 Dodge 1500 4WD				
Part #	Jobber	UPC	Weight	Box Deminsions
K117	1,907.04	804260090050	255	46x40x22
K117B	2,675.02	804260092061	260	46x40x22
K118	2,095.00	804260090074	260	46x40x22
K118B	2,758.28	804260092078	265	46x40x22
4590	676.44	804260072568	72	33x13x7.5
4591	814.97	804260072575	57	33x13x7.5
4592	158.92	804260072582	53	30x24x5
4595	110.05	804260090173	5	22.5x7x5.375
4597	256.71	804260090210	45	33x13x7.5
4597B	1,024.69	804260092047	50	33x13x7.5
4598	444.67	804260090234	50	33x13x7.5
4598B	1,110.95	804260092054	55	33x13x7.5
4580	72.19	804260092030	4	11x2.75x5.375
40002	219.95	804260072537	10	33x13x7.5